




Схема радиотелефона PANASONIC KX-TC109-W







CHARGE CONTACT

Q15-17.21 SW

SW

3.6

0

0

0

0

0

0

0

0


0

0

0

0

0



Pin	Signal	Value
1	VSS	
2	OSC1	
3	OSC2	
4	VDD	
5	SIRQ	
6	DTMF	
7	RESET	
8	SYNC	
9	LINE/25ch	
10	PLL EN	
11	UNLOCK	
12	SQ	
13	RX DATA	
14	BELL/HOOK	
15	POWER DOWN	
16	TX MUTE	
17	MIC MUTE	
18	SP MUTE	
19	KEY IN	
20	KEY IN	
21	KEY IN	
42	TR RLY	
43	BEEP	
44	CHARGE	
45	DATA	
46	CLOCK	
47	(SHUNT)	
48	BEEP CONT	
49	INUSE/INLED	
50	CHARGE	
51	QUICK CHARGE	
52	TX DATA	
53	TX POW	
54	NORMAL	
55	STROBE	
56	STROBE	
57	STROBE	
58	KEY IN	
59	KEY IN	