



Схема радиотелефона PANASONIC KX-TC1450





(6) (7) (8) (9) (10) (11) (12) (13) (14) (15) (16) (17) (18) (19) (20) (21) (22) (23) (24) (25) (26) (27) (28) (29)

RX (1kHz TONE
6kHzdivi)

75 mV

150 mV

92 mV

50 mV

22 mV

3.5 V

IC901 PQVI9046G014

1	VSS
2	VDD
3	XT1
4	XT2
5	RESET
6	BEEP_CNN
7	MIC_MUTE
8	ID
9	CHARGE
10	DATA
11	DATA
12	DATA
13	DATA
14	DATA
15	DATA
16	DATA
17	DATA
18	DATA
19	DATA
20	DATA
21	DATA
22	DATA
23	DATA
24	DATA
25	DATA
26	DATA
27	DATA
28	DATA
29	DATA
30	DATA
31	DATA
32	DATA
33	DATA
34	DATA
35	DATA
36	DATA
37	DATA
38	DATA
39	DATA
40	DATA

