


Схема телевизора Panasonic TX-14S3T

E BOARD
TNP8EE007



JK3102
TJB16863

JK3101

J1

J2

J3

J4

J5


J6

J7

J8

J9

J10



Y BOARD
TNP8EY011 ⚠

(FOCUS)

↑
FOCUS

EHT

Y51-1
 SCREEN
 GT

S351
 0330660069

Q353
 2SC1473ATA

Q351
 2SC1473ATA

Q352
 2SC1473ATA

Q354
 BC857B

E7

Y3

Y2

Y1

+190V

HEATER

GND HEATER

TO E8

GND

BLUE

GREEN

RED

Y BOARD
 TNP8EY011 ⚠