






CABINET	SPEAKER	LOC. NO	SPEC
3373-3336-331F		J214	DELETE
3379	15ohm * 10W / 2-5[W]	R610	R-CA: 13kohm-1/8
10470568		R611	R-CA: 1.8kohm-1/8
		R614	R-FUS: 3.3ohm-2W-AA
		R615	R-FUS: 3.3ohm-2W-AA
5073-5373-8038		C214	RELIEF
5338-5079-5379	15ohm * 10W / 3-0[W]	R610	R-CA: 13kohm-1/8
501F		R611	R-CA: 2.4kohm-1/8
10470568		R614	R-FUS: 2.4ohm-2W-AA
		R615	R-FUS: 2.4ohm-2W-AA
3365-3339-3839		J214	JUMPER
336E-333H	8ohm * 20W / 3-0[W]	R610	R-CA: 12kohm-1/8
501H-333H		R611	R-CA: 4.3kohm-1/8
10470568		R614	RELIEF
20' 21' (39.85-20)		R615	R-FUS: 0.18ohm-2W-AA
331E-501E-5366		C214	RELIEF
336E-386E-5056	8ohm * 20W / 5-0[W]	R610	R-CA: 27kohm-1/8
333E-503E		R611	R-CA: 3.9kohm-1/8
10470574D		R614	R-FUS: 0.47ohm-2W-AA
		R615	R-FUS: 0.47ohm-2W-AA


11-3 SOUND, EXT-A/V (Middle East / Asia)



11-4 POWER / CRT / VERTICAL / HORIZONTAL



11-5 MICOM (TTX)



11-6 MICOM (NON-TTX)




Схема телевизора Samsung CK-1438VR5X/VWT, CK-1448VR5X/BWT, CK-20E3VR5X/NWT, CK-2073XR5X/VWT, CK-2085VR5X/BWT, CK-2173XR5X/BWT, CK-2185VR5S/AWT