



# Схема телевизора Samsung CK-5051A

















PR01  
SC-5R(P)

RIC02  
X24C02P

RIC01  
SPM109B



RIC03  
KIA7042P














TIC01  
KM6264BLS-10



TIC02  
SAA5246P/H-M6

TIC03  
MAB8461P/W115

SIMPLE TTX  
OPTION (DELETE)

TIC04  
TEA2014

PWB-CRT



PWB-TRANSMITTER